# EDL Project: OpenBCI


TUES-06

Aayush Rajesh (200070001) Aditya Sriram (200070004) Shivam Patel (200070077) TUES-18

Ankith R (200070006) Anubhav Bhatla (200070008) Nithish Kumar Reddy (20D070072)


## About our project : BCI

- Brain Computer Interfacing (BCI)
  module developed for tapping
  electrical signals of our brain
- We would like to observe EEG signals under specific stimuli




### Basic Approach


 Three aspects - Terminal Headgear, Acquisition Hardware, Interfacing Software



### Design Overview: Main PCB




## Design Overview: Main PCB



# Design Overview: Demo PCB


- Modular Design for demo purposes
- Easy-to-replicate PCBs to house the ADC with all requisite circuitry, communication pins, and electrode connectors
- Interface this 4-channel model with 3D printed electrode headgear



Evolution of the demo PCB. From top left clockwise: the final modular PCB, a Voltera printed ADC test PCB, and a prototyping board for initial design tests

### Difficulties Faced: Daisy Chain


- Daisy chain is a way of chaining multiple
   ADCs to act like a shift register allows
   efficient communication of data across SPI
- We are able to get the chain running, but since it is highly sensitive to timing, data streams interfere with each other.
- Possible fixes: Tuning SPI timing. Minor differences in SPI clocks seen by each ADC can cause the shift register values to undergo interference.



# DEMO


### Results

- Data from ADC digitally filtered between 1-30 Hz (typical range of EEG signals)
- Spikes visible across all channels whenever subject blinks eye
- More evident on channels 1 and 3 (connected to forehead electrodes)



### Results

- Data from ADC digitally filtered between 8-12 Hz for Alpha wave
- Subject blinks eyes, meditates for 10 seconds, and blinks eyes again
- Alpha rhythm evident when subject is meditating



### Conclusions

#### **Goals Achieved:**

- Acquired EEG data through 4 filtered channels
- Analyzed obtained data for subject response to stimuli we can observe the response for different placements of electrodes on headgear

#### **Further Advancements:**

- Unify components with main PCB soldering, testing, validating
- Migrate and tune codebase for timing restrictions on main PCB
- Modular design allows for stackable Daisy-chained PCBs efficient way of increasing channel count

# Thank You!